


Thermodynamics

Thermodynamics

- Thermodynamics describes processes which include change of temperature, energy transformations and mutual relation between thermal and mechanical energy
- You should know from previous studies:
 - Thermodynamics system
 - Thermodynamics laws
 - Heat, work, enthalpy, entropy, thermodynamics processes,

Thermodynamic system

- Part of a matter volume around which we can draw boundary



Insulated – no matter and energy is exchanged with the surroundings

Closed – no matter is exchanged with the surroundings, energy can be exchanged

Open – energy and matter is exchanged with the surroundings

Thermodynamic balance – the state of thermodynamic system in which all parts are in mechanical, thermal and chemical balance

Thermodynamic process

- **State values** – description of a thermodynamic system in the state of equilibrium (p - pressure, V - volume, U - enthalpy, T - temperature, ...)
- The thermodynamic process occurs when the system changes from one state of equilibrium to another
 - Values of state variables are independent on the manner (path) how the change occurs
 - Values of non-state variables (Q , W) depend on the manner (path) how the change occurs
- Thermodynamic processes are
 - Reversible/Irreversible processes – reversible process can run in both directions, when during the reverse process the system runs through all states as during the direct process
 - Circular – initial and final states are the same

Laws of thermodynamics

- **First** law of thermodynamic

- The change of internal energy dU of isolated system is the sum of change of heat δQ which is introduced to the system and change of work δW which is done on the system

$$dU = \delta Q - \delta W$$

- The volume work δW is the volume change at constant pressure

$$\delta W = p dV$$

- The work has positive sign if the system does work – energy goes out from the system and negative sign if the work is done on the system – energy is added to the system

Laws of thermodynamics

- **Second** law of thermodynamics (derived from empirical observations)

- Entropy definition

$$ds = \frac{\delta Q}{T}$$

- For a reversible system the $ds=0$, spontaneous process $ds>0$
 - Entropy never decreases spontaneously
 - The change of entropy at constant value of temperature is higher at lower temperature
- **Third** law of thermodynamics
 - The entropy of pure solid or liquid matter is equal to the zero at zero absolute temperature

Enthalpy

- Definition of enthalpy H

$$H = U + pV$$

$$dH = dU + pdV + Vdp$$

- Isobaric process $dp=0$

$$dH = \delta Q - pdV + pdV + Vdp$$

$$dH = \delta Q$$


- Adiabatic process $\delta Q = 0$

$$dH = Vdp = -\delta W$$



Carnot cycle

- Teoretical thermal cycle with highest thermal efficiency within the given range of temperature T_1 and T_2 which is independent on medium
- Consists of four processes
 - **1-2** Adiabatic compression between temperatures T_1 and T_2
 - **2-3** Isothermic expansion at temperature T_2
 - **3-4** Adiabatic expansion at temperature drop from T_2 to T_1
 - **4-1** Isothermic compression at temperature T_1



Carnot cycle efficiency

- Efficiency

$$\eta = \frac{\text{total mechanical work of cycle}}{\text{total energy consumed by system}} = \frac{W}{Q_p}$$


- Mechanical work of cycle

$$W = Q_p - Q_o$$

then the


$$\eta = \frac{Q_p - Q_o}{Q_p} = 1 - \frac{Q_o}{Q_p} = 1 - \frac{T_1(s_1 - s_2)}{T_2(s_1 - s_2)} = 1 - \frac{T_1}{T_2}$$

Phase diagram of water




- Triple point of water
 - Temperature $0,01^{\circ}\text{C}$ and pressure 611 Pa
- Critical point of water
 - Critical temperature $t_k = 374^{\circ}\text{C}$ and pressure $p_k = 22,12\text{ MPa}$


T-s diagram (water-steam)



Mollier diagram of water (h-s diagram of water and steam)



Clausius-Rankine cycle



- **1-2-3** Isobaric heating and water vaporization
- **3-4** Isobaric steam overheating
- **4-5** Adiabatic steam expansion in turbine
- **5-1** Isobaric steam condensation v condenser

Clausius-Rankine efficiency

- Determination of introduced heat

$$Q_p = h_4 - h_1$$

- Mechanical work of turbine

$$W = h_4 - h_5$$



- Thermal efficiency of C-R cycle

$$\eta = \frac{W}{Q_p} = \frac{h_4 - h_5}{h_4 - h_1}$$

Increasing of C-R cycle efficiency

- Increasing of temperature and pressure of steam
 - Velké nároky na materiálové, konstrukční a bezpečnostní požadavky
 - Elektrárny s nadkritickými parametry
- Decreasing of temperature and pressure in condenser
 - Limited by ambient temperature
 - Common condensing temperature and pressure 30 °C, 4 kPa
- Repeating of cycle part with highest efficiency
 - Steam re-overheating (multiple as well)


Increasing of C-R efficiency by steam reheating



Regenerative reheating of feed water

- Reheating of feed water between condenser and boiler by heat exchanger
- The heating medium is a steam taken from turbine
- Decreasing of the heat losses in the condenser
→ increase of efficiency

Regenerative reheating system




HPH – high pressure reheater


LPH – low pressure reheater

Losses in turbine


- Friction losses, losses by internal leakages, loss by changing the direction of flow, ...



Losses in feed pump




Energy balance of turbine



$$m_{in}h_a - (m_{o1}h_{o1} + m_{o2}h_{o2} + m_{o3}h_{o3}) - (m_{in} - m_{o1} - m_{o2} - m_{o3})h_e - P_{el} - Q_z = 0$$

Note: m is the mass flow in kg/s, P_{el} is the electric energy, Q_z are energy losses in turbine and generator and h is enthalpy

Energy balance of regenerative reheaters



Energy balance of regenerative reheaters

- VTO

$$m_{o1}h_{o1} + m_p c_w t_{11} - m_p c_w t_{12} - m_{k1} c_w t_{k1} = 0$$


- NTO1

$$m_{o2}h_{o2} + m_p c_w t_{21} + m_{k1} c_w t_{k1} - m_p c_w t_{22} - (m_{k1} + m_{k2}) c_w t_{k2} = 0$$

- NTO2

$$m_{o3}h_{o3} + m_p c_w t_{31} + (m_{k1} + m_{k2}) c_w t_{k2} - m_p c_w t_{32} - (m_{k1} + m_{k2} + m_{k3}) c_w t_{k3} = 0$$

Energy balance of condenser



$$m_k h_e + m_w c_w t_{w1} - m_w c_w t_{w2} - m_k c_w t_k = 0$$

Heat power of condenser:

$$Q_k = m_w c_w (t_{w2} - t_{w1}) = m_k (h_e - c_w t_k)$$

Energy balance of boiler

$$m_p h_{nv} - m_p h_a + m_{pv} q_n - Q_z = 0$$

- Boiler efficiency

$$\eta_k = \frac{m(h_a - h_{nv})}{m_{pv} q_n} = \frac{Q_1}{m_{pv} q_n}$$


- Specific heat consumption

$$q_s = \frac{3\,600 Q_1}{P} \quad (\text{kJ/kWh})$$

- Specific steam consumption


$$m_p = \frac{3\,600 m}{P} \quad (\text{kg/kWh})$$

where P is the electric power
and m is the steam mass flow




Combined heat and power (CHP) production

- Back-pressure turbine





Combined heat and power (CHP) production

- Extraction steam turbine (controlled steam distribution)



Gas power cycle



Combined cycle

